

1. INSTALL CANOPY WITH HARDWARE PACK-THE FIXTURE IS VERY HEAVY UP TO (500 LBS), VERIFY STRUCTURE CAN SAFELY SUPPORT THE WEIGHT OF THE FIXTURE
2. INSTALL UPPER CABLE GRIPPER
3. LACE THE CABLE FROM THE FIXTURE BODY, THROUGH THE CANOPY COVER AS SHOWN, THEN ATTACH TO THE CABLE GRIPPER
4. HANG FIRST SECTION "A" FROM CABLE
5. ROUTE WIRE DOWN CABLE INTO FIRST SECTION
6. ATTACH SECTIONS "B" THRU "D" WITH 1/4-20 BOLTS
7. ATTACH ELEMENT SECTIONS "1" THRU 4" TO MAIN BODY (SEE FOLLOWING LAYOUT)
8. MAKE ELECTRICAL CONNCETIONS
9. INSTALL GLASS -SEE INCLUDED INSTURCTIONS FOR GLASS
10. INSTALL COVER PLATES

